

ZNC400 Nurse Presence Buddy



Key features:

- Combined nurse presence and staff attack alarm
- Staff attack lanyard pull pin and push button triggers
- Portable
- Nurse identification feature



The 'buddy' is a portable, remote, infra-red transmitter trigger. Combining the functionality of the staff attack alarm and nurse presence identification, this 'buddy' allows you to track staff locations as well ensuring their safety which is paramount in the healthcare industry.

The staff attack function has two methods of operation:

- A push button alarm
- Lanyard pull pin

The staff attack function is compatible with the ATX3000/3000+/4000 and ATX5000 call points. The nurse presence identification feature provides a permanent record of the nurse in attendance. This facility allows you to track and monitor individual staff activity i.e. which member of staff is answering which call and when. This helps to provide greater clarity and accountability in care home management. When combined with the Aid Call's Call Logging system, care managers are able to analyse response and attendance times at client and nurse level and help improve overall resource efficiency.

The nurse presence function is compatible with the ATX4000 and ATX5000.

0800 052 3616
sales@aidcall.co.uk

ZNC400

Specifications

Battery Type	<ul style="list-style-type: none">Lithium
Battery Life	<ul style="list-style-type: none">Low Power Mode - Up to 3 years based on 100 activations per dayHigh Power Mode - Up to 3 years based on 5 activations per day
	<ul style="list-style-type: none">Height - 47mmWidth - 95mmDepth - 27mm
	<ul style="list-style-type: none">62g



Aid Call, a business unit of Legrand Electric Ltd
Unit 4 Brunel Court, Brunel Road, Newton Abbot
Devon TQ12 4PB, Tel: **0845 600 3734** Fax: **01626 332 272**
Email: sales@aidcall.co.uk Web: www.aidcall.co.uk